

# Written Décor Application Instructions

- 1- Lay your design white grid paper side up, rub down the piece to insure the letters stick to the clear or milky transfer paper.
- 2- Measure the design to insure it is centered and straight. Measure from the bottom of the letters, keeping in mind that some fonts are jagged. (Therefore, measure letters that are the same.) Securely tape the top edge of the design to the wall using masking tape. Mark the top corners of the clear/milky paper lightly with a pencil.
- 3- Remove the design from the wall and lay it on a hard flat surface, grid side up.
- 4- Carefully peel the grid paper off, working from one side to there other and rolling straight back, allowing the letters to stick to the sticky transfer paper. (If the lettering is not separating, replace the paper onto that letter, rub down, and try again. (Sometimes it helps to push down on the letter as you are pulling back.) Now, match up the top corners with your marks on the wall, making sure to only let the very top of the design touch the wall. Starting at the top, make sure is lies flat and then slowly work your way down and out. Rub with a credit card or pancake turner to push it firmly to the wall.
- 5- Remove the transfer paper by gently pulling straight back. If the words are lifting, just put it back down, press and try again. You may push the letters down with your fingers. Work slowly with patience! Some fonts are easier than others. Small and delicate letters take extra caution and patience.
- 6- Take the piece of grid paper that you peeled off and lay across the design. Firmly rub again for good measure. Please take pictures and email to us at [info@writtendecor.com](mailto:info@writtendecor.com)!! We would love to see what you have created!
- 7- Enjoy your design! Please share us with business colleagues, family and friends!

Feel free to call us with any questions or problems at 1-800-990-0335.  
Happy Creating;

